



1



PREP

2



INFLATE


3



MOVE

SUPPORT LEGS

4



DEFLATE

**BREAK
SMART SEAM™**